

BOOT LACING






Start lacing your boots from the inside to the outside.





You should use the lace keeper.








Pass the laces from the top to the bottom of the hooks.







In the hook area lace tight but without too much pressure.









INCORRECT LACING LEADS TO:

